

**Wiring Instructions: CBS-52H15 (-15)
CBS-52H20 (-15)**

Total Heaters: 3 X 3KW

All heater wires and terminals are numbered. Connect the incoming wires to the terminal block, and the heater wires to the mercury relay as shown for each of the available options.

Option 1
Heaters Connected
2 X 3 KW Phase Volts KW Amps
single 120/208-240 4.6 - 6.1 22.4 - 25.8

Terminal block: Connect incoming wires to L1, L2, N, & Ground

Relay terminal:
H1 - Connect heater wires 1 & 5
H2 - Connect heater wires 4 & 6
H3 - Connect heater wires 2 & 3

Option 2
Heaters Connected
3 X 3 KW Phase Volts KW Amps
single 120/208-240 6.9 - 9.1 33.3 - 38.3

Terminal Block: Connect incoming wires to L1, L2, N, & Ground

Relay terminal:
H1 - Connect heater wires 1, 5, & 2
H2 - Connect heater wires 4, 6, & 3
H3 - No wires connected

Option 3
Heaters Connected
3 X 3 KW Phase Volts KW Amps
3 120/208-240 6.9 - 9.1 19.5 - 22.5

Terminal Block:
Connect incoming wires to L1, L2, L3, N, & Ground

Relay terminal:
H1 - Connect heater wires 1 & 2
H2 - Connect heater wires 3 & 4
H3 - Connect heater wires 5 & 6

**Wiring Instructions: CBS-52H15 (-15)
CBS-52H20 (-15)**

Total Heaters: 3 X 3KW

All heater wires and terminals are numbered. Connect the incoming wires to the terminal block, and the heater wires to the mercury relay as shown for each of the available options.

Option 1
Heaters Connected
2 X 3 KW Phase Volts KW Amps
single 120/208-240 4.6 - 6.1 22.4 - 25.8

Terminal block: Connect incoming wires to L1, L2, N, & Ground

Relay terminal:
H1 - Connect heater wires 1 & 5
H2 - Connect heater wires 4 & 6
H3 - Connect heater wires 2 & 3

Option 2
Heaters Connected
3 X 3 KW Phase Volts KW Amps
single 120/208-240 6.9 - 9.1 33.3 - 38.3

Terminal Block: Connect incoming wires to L1, L2, N, & Ground

Relay terminal:
H1 - Connect heater wires 1, 5, & 2
H2 - Connect heater wires 4, 6, & 3
H3 - No wires connected

Option 3
Heaters Connected
3 X 3 KW Phase Volts KW Amps
3 120/208-240 6.9 - 9.1 19.5 - 22.5

Terminal Block:
Connect incoming wires to L1, L2, L3, N, & Ground

Relay terminal:
H1 - Connect heater wires 1 & 2
H2 - Connect heater wires 3 & 4
H3 - Connect heater wires 5 & 6